


How to Use the Ruler Included in the Boat Package



10cm (4") line on the boat body.



Place the clear plastic ruler on the boat body to match the 10cm line while inflating.