

| <b>Valve Position</b> | <b>Function</b>  | <b>Water Flow Direction</b>   |
|-----------------------|--|---|
| <b>FILTER</b>         | Normal filtration and regular vacuuming of pool                                      | From pump through sand filter media to pool                             |
| <b>BACKWASH</b>       | Reverses water flow to clean sand filter media                                       | From pump through sand filter media to control valve waste/drain outlet |
| <b>RINSE</b>          | For leveling the sand bed after backwashing  | From pump through filter media to control valve waste/drain outlet      |
| <b>WASTE/DRAIN</b>    | For vacuuming directly to waste, lowering pool water level or to drain the pool      | From pump to valve waste/drain outlet bypassing the filter media        |
| <b>RECIRCULATE</b>    | For circulating water back to pool without going through the filter media            | From pump through valve to pool bypassing the filter media              |
| <b>CLOSED</b>         | Shuts off all flow to filter and pool<br>"Do not use this setting with pump running" | N/A   |